



INSTRUCTION MANUAL


MOUNTING CONSTRUCTION PLASTER RING - GLARELESS SPOT

STEP 1

- Drill a hole in the ceiling with a hole saw of \varnothing 88mm. Keep in mind the total width of the ring is 130mm.

NECESSITIES

- Hole saw - \varnothing 88mm
- Drill




STEP 2

- Attach the wooden ring with the adhesive strip around the drill hole above the ceiling.

NECESSITIES

- Two half wooden rings




STEP 3

- Place the plastering in the drill hole and screw the plastering tight with drywall screws.

NECESSITIES

- 5 times recessed drywall screws
- Screwdriver







INSTRUCTION MANUAL

MOUNTING CONSTRUCTION PLASTER RING - GLARELESS SPOT

STEP 4


- Plaster the ceiling

CAUTION: SMOOTH THE PLASTER
EVENLY WITH THE BLACK CAP



STEP 5


-After the plastering is complete. Pierce the hole in the center of the cap with a screwdriver and pry it out of the ceiling.



STEP 6

-Look for the cabling of the spot in the datasheet on the website via the QR code on the last page.

-press the spot front into the plastering






INSTRUCTION MANUAL

MOUNTING CONSTRUCTION PLASTER RING - GLARELESS SPOT

STEP 7

- To disassemble the spot, use a voltage finder to pry the spot up in the open lip of the plastering





COMPATIBILITY TABLE

MOUNTING CONSTRUCTION FOR LED-SPHERE

DRIVERS AND ENGINES

	EXTERNAL DRIVER				INTERNAL DRIVER	
	CASAMBI	DMX	DALI	0-10 VOLT	CASAMBI	DMX
GLARELESS SPOT SINGLE WHITE	X	X	X	X		
GLARELESS SPOT DUAL WHITE/ WARM DIMMING	X		X		X	X
GLARELESS SPOT DUAL WHITE / TUNABLE WHITE	X	X	X		X	X
GLARELESS SPOT RGB+W					X	X
LED-SPHERE BASIC DUAL WHITE/ DUAL WHITE					X	X
LED-SPHERE PREMIUM RGB+W/ DUAL WHITE					X	X
LED-SPHERE ULTIMATE RGB+W/ RGB+W					X	X
POWERLINE SINGLE WHITE	X				X	X
POWERLINE DUAL WHITE / WARM DIMMING					X	
POWERLINE DUAL WHITE/ TUNABLE WHITE					X	X
POWERLINE RGBW+W					X	X
OUTDOOR ENGINE					X	

MANUALS

WWW.DYDELL.COM

Want to know more about the wiring and connecting the engine to the driver? Scan the QR code below to go to the instruction page on our website. Is the QR code not working? Copy this link: <https://www.dydell.com/nl/video-instructies-handleidingen/> into your browser.

