

# MOUNTING SPECIFICATION

MOUNTING CONSTRUCTION FOR SPRING CLIP GLARELESS SPOT

## STEP 1


- Drill a hole in de ceiling with a hole saw of  $\varnothing$ 76mm

#### WHAT YOU NEED:

- Hole saw Ø 76mm
- Drill


## STEP 2

- Install the spots
- Go to: www.dydell.com/nl/video-instructies-handleidin gen/ or scan the QR code for more instructions



### STEP 3

- Squeeze in de the springs of the spot and place the spot In the ceiling hole



#### **DRIVERS AND ENGINES**

	EXTERNAL DRIVER				INTERNAL DRIVER	
	CASAMBI	DMX	DALI	0-10 VOLT	CASAMBI	DMX
GLARELESS SPOT SINGLE WHITE	x	X	x	x		
GLARELESS SPOT DUAL WHITE/ WARM DIMMING	х		x		X	Х
GLARELESS SPOT DUAL WHITE / TUNABLE WHITE	x	X	х		x	х
GLARELESS SPOT RGB+W					x	х
LED-SPHERE BASIC DUAL WHITE/ DUAL WHITE					x	х
LED-SPHERE PREMIUM RGB+W/ DUAL WHITE					x	х
LED-SPHERE ULTIMATE RGB+W/ RGB+W					x	х
POWERLINE SINGLE WHITE	x				x	х
POWERLINE DUAL WHITE / WARM DIMMING					x	
POWERLINE DUAL WHITE/ TUNABLE WHITE					x	х
POWERLINE RGBW+W					x	x
OUTDOOR ENGINE					x	

# **MANUALS**

WWW.DYDELL.COM

Want to know more about the wiring and connecting the engine to the driver? Scan the QR code below to go to the instruction page on our website. Is the QR code not working? Copy this link: https://www.dydell.com/nl/video-instructies-handleidingen/ into your browser.



